

Keysight E8361C (PNA) Connection & Setup

Firmware Supported

To check your firmware version refer to your manual or restart your Network Analyzer, the firmware number will appear on the LCD.

Rev. A.09.33.09

Note

E8361C model tested.

Setup Requirements

Go to System, Configure, SICL/GPIB/SCPI set SICL to enable
Check mark "Automatically Enable on Start up"
Check mark "LAN and Sockets/Telnet"

Connections

