

Keysight ENA 5071B Connection & Setup

Firmware Supported

To check your firmware version refer to your manual or restart your Network Analyzer, the firmware number will appear on the LCD.

Rev. A.09.10

Setup Requirements

1. Go to System, Misc Setup, Network Setup
2. Enable SICL-LAN Server to ON, SICL-LAN Address = 17 and Webserver to ON

Connections

