

Rohde & Schwarz ZNB Connection & Setup

Firmware Supported

To check your firmware version refer to your manual or restart your Network Analyzer, the firmware number will appear on the LCD.

Rev. V2.82

Note

ZNB8 model is tested.

Options

ZNB-B10	GPIB Interface
ZNB8-B22	Extended Power Range Ports 1-2
ZNB8-B31	Receiver Step Attenuator Port 1
ZNB8-B32	Receiver Step Attenuator Port 2

Connections

