

Rohde & Schwarz FSW Connection & Setup

Firmware Supported

To check your firmware version refer to your manual or restart your Spectrum Analyzer the firmware number will appear on the LCD.

Rev. 2.71

Required Options

External trigger port 1

Connections

